




## User Manual GB

### ◆ Instruction



- Charge: Insert USB cable into Micro USB socket, and also connect the adapter DC5V 1A or above;
- When charging, the indicator light will turn on. When fully charged, the light automatically turns off;
- When use the battery to lit lamp, no need to connect the adapter;



- The buzzer sounds


Touch the switch to turn on/off the lamp (Pls refer to the operational instructions)

- When adjust the rotation of lamp head, please hold the base.
- Up-Down rotation of the lamp is 180° (Over-adjust may cause joint activity parts damage)

### ◆ Specification

|               |            |                |             |
|---------------|------------|----------------|-------------|
| Materials     | ABS        | CRI            | Ra>80       |
| Light Source  | LED        | Input          | 5V/1A       |
| Power         | 5W         | Li-ion Battery | 2000mAh     |
| Luminous flux | 260lm      | N.G.           | 460g        |
| CCT           | 2700-6000K | Product Size   | 95*72*500mm |

### ◆ Instruction



- Touch switch, can adjust CCT & brightness
  1. Short touch to turn ON/OFF
  2. Short touch to change CCT-3 grade
  3. Long touch to adjust brightness
  4. Memory function of brightness



Time / Snooze  
Time  
Calendar  
Temperature

### ◆ Attention


- If touch Power switch can not lit the lamp, please make sure the base switch in ON position and also battery fully charged;
- Please use adapter DC 5V 1A or above;
- Can not be used on more than 6° slope or unstable places;
- Can not be placed on combustible and humid places;
- If need inspection and repair, please entrust qualified electrical professional electrical engineer operation;
- Do not look at the LED light source directly to avoid hurting eyes.





EKO-LIGHT Sp. z o.o. Sp. k. Al. Wojska Polskiego 63  
42-200 Częstochowa / www.eko-light.com  
☎ +48 666 503 333 ✉ sales@milagrolighting.eu

## Instrukcja użytkownika PL

### ◆ Instrukcja



- Ładowanie: Włóż kabel USB do portu micro USB, i podłącz do ładowarki DC5V 1A lub o większej mocy;
- Podczas ładowania, dioda będzie się świecić. Przy pełnym naładowaniu zgaśnie;
- Używając baterii jako zasilania, nie należy ładować lampki;



- Dźwięk budzika


Dotknij przełącznika, aby wł. / wył. lampę.

- Podczas ustawiania kąta padania światła przytrzymaj podstawę lampki.
- Obrót lampy w górę-w dół wynosi 180° (Szerze rozchylenie może powodować uszkodzenie części lampy)

### ◆ Specyfikacja

|                   |            |                |             |
|-------------------|------------|----------------|-------------|
| Materiał          | ABS        | CRI            | Ra>80       |
| Źródło światła    | LED        | Napięcie       | 5V/1A       |
| Moc               | 5W         | Li-ion Bateria | 2000mAh     |
| Strumień świetlny | 260lm      | Waga netto     | 460g        |
| CCT               | 2700-6000K | Wymiar         | 95*72*500mm |

### ◆ Instrukcja



- Włacznik
  1. Przyciśnij raz aby włączyć/wyłączyć.
  2. Przyciśnij raz aby zmienić barwę światła.
  3. Przytrzymaj dłużej aby zmienić natężenie światła.
  4. Funkcja pamięci jasności



Czas / Drzemka  
Czas  
Kalendarz  
Temperatura

### ◆ Uwaga

- Jeśli lampka nie świeci, upewnij się czy przycisk główny (w podstawie lampy) jest w pozycji ON, oraz czy bateria jest w pełni naładowana;
- Używaj ładowarki DC 5V 1A lub o wyższych parametrach;
- Nie używać na powierzchniach o kącie nachylenia 6° lub większym;
- Nie używać w wilgotnych miejscach;
- W przypadku naprawy skontaktuj się z serwisem producenta;
- Nie wpatruj się bezpośrednio w źródło światła.



EKO-LIGHT Sp. z o.o. Sp. k. Al. Wojska Polskiego 63  
42-200 Częstochowa / www.eko-light.com  
☎ +48 666 503 333 ✉ sales@milagrolighting.eu




## Obsługiwanie funkcji Kalendarza i Trybu Budzika

### Ustawianie daty i czasu

1. Podczas trybu zwykłego (pokazywania godziny) wciśnij SET, wprowadź datę i godzinę.
- Wciśnij SET ponownie, aby przejść do następnych ustawień: godzina-minuta-rok-miesiąc- dzień- powrót.
- 2.Wciśnij GÓRA lub DÓŁ by zmienić dzień tygodnia
3. By powrócić z ustawień do trybu zwykłego wciśnij MODE lub poczekaj 60 sekund.
4. W trybie zwykłym wciśnij UP by zmieniać format godzinny między 12 a 24

### Ustawianie Trybu Budzika

- 1.Wciśnij przycisk TRYB by wejść w Tryb Budzika
  - 2.W Trybie Budzika wciśnij SET i wpisz godzinę alarmu, wciśnij SET ponownie by wybrać inne funkcje: godzina, minuta, rok, miesiąc, dzień, powrót
  3. Wciśnij GÓRA i DÓŁ by ustawiać.
  - 4.W Trybie Budzika wciśnij Góra lub Dół by włączyć i wyłączyć drzemkę i alarm.
- Dostępne funkcje: Włącz alarm, włącz drzemkę, wyłącz alarm i drzemkę.
5. Dzwoniący alarm wyłącza się po minucie i wchodzi w tryb drzemki po czym dzwoni jeszcze raz, Wciśnij SET lub jakikolwiek inny przycisk by wyłączyć alarm.



### Operation for Setting Calendar and Alarmd snooze

#### Date and Time setting

- 1.Under normal mode,press SET key enter date and time setting mode , press SET again to enter the next setting,the sequence of setting as below:Hour-minute-year-month-day-back
- 2.Press UP and DOWN setting,the day of week will vary accordingly.
- 3.Under setting mode,Press MODE or no operation in 60 seconds will back from set mode,and display the time.
- 4.Under normal mode,press UP transfer 12 and 24 hours format.

#### Snooze function setting

- 1.Under normal mode,press MODE enter alarm mode.
- 2.Under alarm mode,press SET enter alarm setting,press SET again enter the next setting,the sequence of setting as below:  
Hour-minute-year-month-day-back
- 3.Press UP and DOWN key to set.
- 4.Under alarm mode,press UP and DOWN key can open and close the snooze and alarm,press it again enter the next function,the sequence as below:Open the alarm-open the snooze -close alarm and snooze
- 5.When reach the alarm, the alarm will last 1 minute,snooze time reach, alarm will ring again,press SET key or any button can stop the alarm.